



High Temperature Oxygen Out-Diffusion from the Interfacial SiO_x Bond Layer in Direct Silicon Bonded (DSB) Substrates

Jim Sullivan, Harry R. Kirk, Sien Kang, Philip J. Ong, and
Francois J. Henley

Silicon Genesis Corporation
San Jose, California USA

IEEE 2006 International SOI Conference

Niagara Falls, New York
2 – 5 October, 2006

Outline




2

- Motivation for DSB
- Adapting an SOI Process for DSB
 - Fundamental Issues & Challenges
- Plasma Bond Process Modifications
- SiO_x Metrology Considerations
- Bond Interface Oxygen Dissolution
 - Relevant Prior Work
 - Theoretical Model
 - Results
 - Special Process Considerations
- Cost-Effective Commercialization
- Conclusions

Motivation – Better CMOS Mobility

$$\text{Delay} \sim \frac{C \cdot V}{I}$$




- Finding ways to increase channel mobility is key
 - Strain and orientation are two good knobs

Hybrid Orientation - Why It Works




4

- Independently optimizes PMOS and NMOS Mobility
- Compatible with strain enhancement approaches
- DSB is a bulk-like, electrically connected version






Electron mobility is highest on (100) surface
Hole mobility is highest on (110) surface




Major DSB Benefit – Bulk-Like!

- Compatible with CMOS processes and strain enhancement approaches
- Amorphization & SPE processes to express selective orientation



CMOS Structure



TEM

Two Major Paths to Consider

1. Hydrophillic Bonding

- Positive Points
 - Used in SOI in production
 - Highly engineered void-free bonding
 - Equipment and bond processes available
- Negative Points
 - Generates a bond interfacial oxide
 - Electrically insulating interface

} Can we eliminate the oxide?

2. Hydrophobic Bonding

- Positive Points
 - No Interface oxide
- Negative Points
 - Void-free bonding is difficult
 - No production low-temperature bond experience
 - Production equipment and processes unavailable

Plasma Activation (PA) for DSB – SiOx Control





7

- Low temperature cleaving possible
- Void-Free Production Bonding
- Control of SiOx at interface



SiGen plasma-activation chamber (open chamber in background) integrated into an EV850 bond tool








SiO_x Metrology Considerations



- SiO_x elimination requires good metrology
- SiO_x stoichiometry used TEM and SIMS
 - First measurements gave $x=4$!
 - SIMS technique had to be refined:
 - Detected CsO⁺ secondary ions with Cs⁺ primary beam)
 - This approach minimize the typical matrix effects in SIMS analysis and allows accurate quantification in presence of interfaces
- SiGen/CEA successfully developed an effective characterization method based on “Calibrated SIMS”
- Method Development:
 - Measured samples with TEMs and SIMS Cs⁺
 - Generated an effective correlation of total oxygen dose versus TEM thickness
 - Dissolution results in good agreement with absolute oxygen numbers


SiO_x Metrology Considerations




- A linear relationship between TEM thickness and SIMS oxygen content was found

=> Quantification was accurate

Pre-Dissolution



Bonded Si-Si Interface




Interfacial layer = $\sim 30\text{\AA}-60\text{\AA}$


Bond Interface Oxygen Dissolution

Post-Cleave Treatment Anneal for elimination of SiO_x interface layer

- High-T anneal after surface treatment in inert or reducing atmosphere (ex. Argon, Hydrogen)
- Allows Oxygen to diffuse and escape from surface
- Requires clean surface & free from getter sites
- Single-crystal silicon grows by solid-phase epitaxy to close the interface as the oxygen and other interfacial elements are diffused out



Bond Interface Oxygen Dissolution




Theoretical Model

$$Flux = -D(dC/dx) \approx \frac{D(C_s - 0)}{t(film)}$$

Fick's Law

$$D = 0.14 \exp(-2.53eV / kT) \frac{cm^2}{sec^2}$$
$$C_s = 9.1E22 \exp(-1.57eV / kT) cm^{-3}$$



Diffusion Calculation (Example)



15

- Parameters

- Silicon Layer thickness (t_{Si}): 200 nm
- Argon Ambient, 1200 °C treatment
- 50 Å interface layer, $SiO_{0.5}$ stoichiometry

- Diffusion Law (oxygen in silicon)

$$\text{Flux (atoms/cm}^2\text{ – sec)} = D_o(T) * [(C_S(T) - 0) / t_{Si}]$$

- At 1200 C, $C_S(T) \sim 4.6 \text{ E}+17 \text{ cm}^{-3}$, $D_o(T) \sim 3.15 \text{ E}-10 \text{ cm}^2\text{/sec}$

- Flux = $7.24 \text{ E}+12 \text{ O-atoms/cm}^2\text{-sec}$


- Total O-Dose = $[4.4 \text{ E}+22 \text{ cm}^{-3} / 4] * 5\text{nm} = 5.5 \text{ E}+15 \text{ atoms/cm}^2$

$$\text{Time} = \text{Total O-dose} / \text{Flux} = 5.5 \text{ E}+15 \text{ atoms/cm}^2 / 7.24 \text{ E}+12 \text{ O-atoms/cm}^2\text{-sec}$$


Time to dissolution = 760 seconds

Oxide Dissolution Kinetics – Experimental Verification


1190 °C
(H-Ambient)




55 Å




0% dissolved



40% dissolved




70% dissolved




100% dissolved





(110) Silicon DSB on (100) Silicon Test Sample







Edge Top and Bottom Diffraction



Local Area Diffraction Patterns




TEM: Pre/Post H-Anneal Tests



<110> direction (across and along view)

Interfacial Layer Reduced to 1-2 monolayers


Oxide free hybrid interface




$\langle 110 \rangle$

$\langle 100 \rangle$

SIMS – SiO_x Layer Dissolution Confirmed




As-Cleaved



Post Anneal

Special Process Considerations


- Solid phase epitaxial re-growth of crystalline silicon during out-diffusion
- Avoidance of oxygen clustering (Ref # 6)
- Metrology of oxygen in SiO_x
- Choice of Handle Material
 - Little difference between CZ & FZ
- Surface oxide and ambient
 - No Surface Oxides!



No Dissolution

Anneal ambient must be oxygen free
.....trace amounts will prevent oxygen out-diffusion

Cost-Effective Commercialization



- **High Throughput Options**
 - Select thinner upper silicon thickness speed out-diffusion
 - Re-grow silicon to desired thickness epitaxially

Conclusions



24

- Plasma-activated bond and cleave effective at controlling defects and interfacial oxide for as-cleaved DSB materials
- Oxygen out-diffusion may be employed to reduce the interfacial oxide to zero or desired target levels

DSB can be commercialized cost-effectively using a SOI layer-transfer process variant for next-generation CMOS process nodes